

# Cooling Vests



CCV-ARC-R

\*shown with CCV-PK

- FR Cooling vest **MUST** be used in conjunction **WITH AND** under the appropriate arc flash protection.
- Vest is **NOT** intended as primary arc flash protection.
- Each vest comes with one set of eight (8) cooling packs.
- Cooling time approximately one (1) hour. Cooling time may vary depending on ambient temperature and exertion level of wearer.
- Cooling packs may be placed in freezer or ice water for activation.
- Regular (R) size fits 5' - 5'10"

Part Number	Description
CCV-ARC-R	Jacket Style Cooling Vest (includes 1 set of 8 cooling packs)
CCV-PK	Replacement Cooling Pack (1 Pack)
CCV-PKS	Replacement Cooling Pack (8 Pack)

### **Wear Tips**

*Wear the cooling vest snug to the body (not tight) to the rib cage to provide cooling for upper torso for maximum cooling effect.*

- *For ideal comfort, place cool packs in ice water before using. A spare set can be kept in cooler and rotated with those in vest for continuous use.*
- *Freezing the packs will extend the cooling time but the temperature difference will be more noticeable to the body.*